


## **Moog Modular Ic**

### **Modules**

**901\***  
**901A**  
**901B(x2)**  
**902(x2)**  
**903A**  
**904A**  
**905**  
**907**  
**910**  
**911(x2)**  
**950**  
**956**  
**991\***  
**994\***  
**CP3(x2)**  
**CP4\***  
**CP8\***

**(\*) Doesn't appear in schematics**






FIGURE 7 OSCILLATOR 901B


## 902 VOLTAGE CONTROLLED AMPLIFIER TEST PROCEDURE

1. Connect dc voltmeter to TP-L (collector of Q5); low side to ground.
2. Turn FIXED CONTROL VOLTAGE pot to 6 and set CONTROL MODE switch to "EXP." DC voltage should read approximately zero.
3. Rotate FIXED CONTROL VOLTAGE pot to 0. DC voltage should read approximately +0.24V.
4. Set CONTROL MODE switch to LIN. DC voltage should read approximately +1.2V.
5. Rotate FIXED CONTROL VOLTAGE pot to 6. DC voltage should read approximately -4.8V.

### NOTE


If the above voltages are observed, the adder section (Q1 thru Q5) is operating properly.

6. With FIXED CONTROL VOLTAGE in 6 and dc voltmeter connected between one of the SIGNAL OUTPUTS jacks and ground, adjust OUTPUT BIAS trimpot for zero volts.
7. Connect dc voltmeter across positive terminals of SIGNAL OUTPUTS jacks. Connect jumper between collectors of Q8 and Q9 and adjust OUTPUT BALANCE trimpot for 0 VDC.
8. Remove jumper across collectors of Q8 and Q9 and connect across collectors of Q6 and Q7. Adjust Q8 and Q9 BALANCE trimpot for 0 VDC.
9. Remove jumper and adjust INPUT BALANCE trimpot for 0 VDC.
10. Turn FIXED CONTROL VOLTAGE pot and ascertain that there is no large offset. If necessary, repeat steps 7, 8 and 9.
11. Turn FIXED CONTROL VOLTAGE pot to 6. Apply 0db 1kHz sine wave to one of the SIGNAL INPUTS. Signal output should be approximately +5db to +7db.
12. Note the output level. Set the CONTROL MODE switch to "EXP." Adjust INPUT BIAS to obtain a level equal to that noted in the "LIN" position.



13. Slowly turn FIXED CONTROL VOLTAGE pot from 6 to 0 and check for linear action in the LIN mode and exponential action in the EXP mode. At 0, signal output should be -60db maximum.
14. Turn FIXED CONTROL VOLTAGE pot to 6. With a dc bias, check each control input for proper voltage control. 0 volts should have no effect, -6 volts should cut the amplifier off completely.
15. With no signal input and FIXED CONTROL VOLTAGE set at 6, output noise should be -60db maximum.


- ① Adjusts + output balance for exponential dc voltages with FIXED CONTROL VOLTAGE CONTROL fully counterclockwise.
- ② Adjusts zero output offset with FIXED CONTROL VOLTAGE control fully counterclockwise.
- ③ Adjusts zero output offset with FIXED CONTROL VOLTAGE control fully clockwise.
- ④ Adjusts amplitude level balance between linear and exponential mode with FIXED CONTROL VOLTAGE control full clockwise.




MOOG MUSIC INC.

SCHEMATIC, 902 VOLTAGE CONTROLLED AMPLIFIER  
993-041813

FIGURE 9 VOLTAGE CONTROLLED AMPLIFIER MODEL 902





NOTES:

1. ALL NPN TRANSISTORS: 2N 3392

2. ALL PNP TRANSISTORS: 2N 4058

3. (M)  $\Rightarrow$  MATCHED PAIR

4. RANGE CAPACITOR SIZES

- |   |               |
|---|---------------|
| 1 | $1.2 \mu F$   |
| 2 | $0.3 \mu F$   |
| 3 | $0.075 \mu F$ |

904-A VOLTAGE CONTROLLED  
LOW PASS FILTER

DRAWN BY P.Y. SCHEMATIC


APPR. BY DATE 7-25-67 DRAWING NUMBER SUPERCEDES NO. 1039 1149

| REV. E  | REV. D  | REV. C   | REV. B  |
|---------|---------|----------|---------|
| 7-25-67 | 7-25-67 | 11/10/70 | ECN-003 |
| WGS     | JLA     | WGS      | ECN-003 |

R. A. MOOG CO.  
THUMANSBURG, N.Y.

## NOTES:

- ALL TRANSISTORS ARE 2N2926 OR 2N3707 UNLESS OTHERWISE MARKED
- MOUNTING SHOULD BE AWAY FROM POWER SUPPLIES, MOTORS AND OTHER DEVICES PRODUCING STRONG MAGNETIC FIELDS
- MOUNTING SHOULD BE AS RIGID AS POSSIBLE TO AVOID MOVEMENT OF THE ACOUSTIC DELAY LINE



## 905 REVERBERATION UNIT

## A. GENERAL

The 905 Reverberation Unit utilizes a dual spring-type acoustic delay line to produce a succession of decaying echoes of an audio signal. A single panel control determines the ratio between the amounts of reverberated and non-reverberated signals that appear at the output jack. The front panel control does not alter the characteristic decay time of the echoes, since this is a function of the delay line itself.

Instructions for mounting and connecting of power, and input and output characteristics, are the same as those which apply to all 900 series modules. However, special consideration in mounting the 905 must be observed. First, power supplies, motors and other devices producing

strong magnetic fields should be kept away from this instrument to avoid the pickup of power line frequency hum. Second, the mounting should be rigid to avoid shaking the acoustic delay line which would result in unwanted output signals. Third, monitor speakers should not be mounted close to the 905, as this would encourage acoustic feedback between speaker and delay line.

Before the 905 is installed, fittings and wrappings restricting the motion of the delay line should be removed. When the 905 is mounted vertically, the delay line bracket will be supported entirely by the suspension springs, and should not touch the chassis frame.


## B. APPLICATIONS

When a dynamically varying signal is applied to the input of the 905, the output will consist of a series of closely spaced echoes, the subjected

## BOTTOM VIEW

effect of which is similar to that of reverberation of sound. If a small amount of "echo signal" is mixed with a larger amount of "direct signal" (REVERBERATION Control set slightly clockwise), the effect of a typical concert hall is obtained. If the echo signal only is passed (REVERBERATION Control set fully clockwise), an exaggerated echo suggesting a cave is obtained. The relative amount of echo signal and direct signal can be continuously changed from 100 percent direct signal to 100 percent echo signal.

When a static signal is applied to the input of the 905, the output will also be static. There will be no sensation of echo. Rather, the 905 will perform in this application like a formant filter, strongly coloring the timbre of any signal with appreciable harmonic content.



993-042648

FIGURE 14 REVERBERATION UNIT MODEL 905

5H




FIGURE 15 FIXED FILTER BANK MODELS 907 AND 907A





FIGURE 16 POWER SUPPLY MODELS 909 AND 910



NOTES:

- I. ALL PNP TRANSISTORS ARE 2N4058
- II. ALL NPN TRANSISTORS ARE 2N3904

REPLACES DWG 1103

| W/R | C-ECN-004 1-12-69<br>2L8 | REVISIONS       |          |
|-----|--------------------------|-----------------|----------|
|     |                          | A-B15 FROM 1.5K |          |
|     | To B20A                  |                 |          |
|     | A - R41 FROM Q5          |                 |          |
|     | To E12K                  |                 |          |
|     | B - ECN-002              |                 |          |
|     | DATE 8-14-68 CKD BY      | 1220            | DWG. NO. |


R. A. MOOG CO.  
TRUMANSBURG, NEW YORK

911 ENVELOPE GENERATOR

## KEYBOARD SWITCHES

### **CONTROLLER CABLE**


| TERM. | FUNCTION        | COLOR | WIRE |
|-------|-----------------|-------|------|
| A     | +12             | RED   |      |
| B     | GND             | BLACK |      |
| C     | - 6             | BLUE  |      |
| D     | CONTROL VOLTAGE | GRN   |      |
| E     | _____           | _____ |      |
| F     | _____           | _____ |      |
| G     | TRIGGER         | BRN   |      |
| H     | TRIGGER GND     | WHITE |      |



CIRCLED NUMBERS ARE TERMINALS  
ON AMP CONNECTOR.

△ LETTERS IN TRIANGLES ARE  
CONTROLLER CABLE CONNECTIONS.

|   |  |   |
|---|--|---|
| REVISIONS   |  | R. A. MOOG CO.<br>TRUMANSBURG, NEW YORK |
| C2 WNS 2.5, HORN 4-6<br>CL 3 HUG, ESN 9010<br>MOVED PORTAMENTO<br>TO LEFT SIDE OF KEY |  |   |
| B   |  | TITLE 950 KEYBOARD                      |
| SCALE   |  | DR. BY JLA                              |
| DATE 4-25-65  |  | KD. BY 1266                             |



NOTE: ALL UNLABELED TRANSISTORS OF TYPE 2N3392

### 956 RIBBON CONTROLLER TEST PROCEDURE

1. Connect the 956 Ribbon Controller to the test rack.
2. Patch TRIGGER output of the 956 to the 911 Envelope Generator, then to the 902 Voltage Controlled Amplifier. Connect SIGNAL OUTPUT of a voltage controlled oscillator to the 902 SIGNAL INPUT. Connect 902 SIGNAL OUTPUT to a monitor amplifier and speaker.
3. Connect PITCH output to the voltage controlled oscillator CONTROL INPUT.
4. Touch TRIGGER bar on the 956. Oscillator should be heard. Adjust the 911 and 902 for a square envelope.
5. Set SCALE to "1" and LOW END VOLTAGE to "0".
6. Slide finger up and down the ribbon while touching the TRIGGER bar. A pitch change should be heard.
7. Adjust the ZERO ADJ. trimpot for 0.0 volt dc indication at PITCH OUTPUT jack.
8. Adjust the -1V. ADJ. trimpot for a 1.0 dc indication when switching between 0 and -1 low end voltage. Trimpot offsets - 1 volt position only.
9. Play the ribbon. It should have a 6.0 volt dc span (six octaves). Decrease the SCALE setting to "5". The ribbon should now span 3.0 volts (three octaves).
10. Slowly play the ribbon listening for erratic pitch changes. If erratic conditions exists, lightly sand the resistance wire and underside of ribbon with No. 400 emery paper. Apply a light film of cramolin to the resistance wire and ribbon to further promote a smooth contact.
11. Depress and release ribbon at low, middle and high end with scale at "10". Check for drift of the sample hold circuit at each of these points. Drift shall be less than 10 mv/minute as measured at the PITCH CONTROL OUTPUT jack.




FIGURE 2 CONSOLE PANEL MODEL 3